



Microwave Oven

The safety regulations:

- ✓ Never close lids on jars and boxes completely.
- ✓ Eggs in a Cup can't be heated in the oven
- ✓ Food with a shell must be pierced first before heated
- ✓ Never use the machine on microwave when its empty
- ✓ Never use any metal in the microwave, this can give sparks and will damage the machine.

Control Microwave function

1. Turn function knob once to the right for the Microwave function (Nr. 1).
2. Set power (Nr. 2).
3. Set time (Nr. 3)
4. Press Start (Nr. 4).



Control oven function

1. Turn function knob four times to the right for the Oven function (Nr. 1).
2. Set temperature (Nr. 2).
3. Set time (Nr. 3)
4. Press Start (Nr. 4).

